


# CRAFT MINI HEAT PRESS


2" x 3"  
6.1 x 10.6 cm

110V Power 180W  
220V Power 250W



## USER MANUAL

## KNOW THE MACHINE



- 1. Temp. Adjustment Button
- 2. 3 Different Temp. Indication
- 3. Safety Insulation Base
- 4. Ergonomic Handle
- 5. Heating Platen
- 6. Power Cord

Press power button for 3 seconds to turn on/off.



**Power Setting**  
Press the button

- H ≈ 190°C/374°F
- M ≈ 160°C/320°F
- L ≈ 140°C/284°F

**Red light Heating-up**

- H
- M
- L

**Reaching to the setting temperature**

- H
- M
- L

Automatic shut off after ten minutes if you're not using it!

## HOW TO PRINT YOUR FIRST BAG?



1. Fix the image on the bag with thermal tape;



2. Turn on the power, press for 3 seconds to turn on, the red light turns on to start heating, and the green light turns on to reach the preset temp;



3. Place the item on the platform, and it is recommended to put a mat under the corresponding position to ensure flatness;



4. Press for about 25 seconds to complete the pattern transfer; the mini heat press machine will automatically shut down if it is not used for 10 minutes;

## WARNING

1. Please place the heat press machine on the safety base when not in use;
2. Keep the machine out of reach of children to avoid accidental contact and burns;
3. Do not immerse the mini heat press machine in water;
4. If the socket outlets in your home are not suitable for the plug supplied with this machine, the plug should be removed and the appropriate one fitted;
5. Do not use the heat press machine if it has been dropped or with visible signs of damage;
6. Do not leave the machine unattended when it is connected with the power;
7. Mini heat press machine is not intended for use by persons with reduced physical, sensory or cognitive capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of Machine by a person responsible for their safety;
8. Do not let the power cord come into contact with the hot sole plate of the mini heat press;
9. Do not use outdoors, the mini heat press machine is intended for household use only;
10. The sole plate can be extremely hot and may get burns if touched.



## PRINTING PARAMETERS

Product						
Product name	Faux Rhinestone	Cap	Keychain	Sublimation Hardboard ornament	Socks	Vinyl
Temperature	M	L	L	L	L	M

Adjusting the temperature and applying different pressures according to different items;